


# Supercal 5



## Backup battery in the calculator upper part

The upper part of the calculator, which is relevant for calibration and measurement, is equipped with an A-cell battery. This serves as power supply for the LCD display when the upper part of the calculator is removed from the lower part or when no power supply is available. The battery has a service life of about 10 years in the backup function.


## Safety instructions

The calculator is manufactured and tested according to EN 61010 safety control for measuring units and left the factory in perfect safety technical condition. To maintain this status and to guarantee the safe operation of the calculator, the user must respect the instructions contained in this document. When opening covers or removing parts, parts under power can be accessed. Further connection terminals can be under power. All repair and maintenance work may be only implemented by a trained and authorized specialist. If the housings and/or the connecting cable show any damage, the calculator unit should be disconnected and secured against accidentally reset up – put in operation. Generally, avoid an installation situation with an accumulation of heat above average. An above-average heat build-up affects substantially the lifetime of the electronic components. Heat meters are measuring devices and must be handled with care. To protect the unit against damage and contamination, the packing should be only removed at the moment of installation. For cleaning just use water moistened cloth and no solvent. The connecting and connection cable may not be fastened on the pipe and under no circumstances be isolated together with the pipe.

## Function test


After opening the shut-off valves, the system must be checked for leaks. Then, by repeatedly pressing the user button, various operating parameters such as flow rate, output and flow and return temperature can be read on the LCD display of the calculator. If modules are installed, this is also shown on the LCD display (M1;M2). With the Superprog Windows and Superprog Android software, you can read additional information from the unit. **All parameter displays are used to check the thermal energy meter or to adjust the system. It must be checked that the regulated flow of the system does not exceed the maximum permitted flow of the meter. A commissioning protocol via the optical interface with the readout software is recommended for a comprehensive functional check.**

## Pressure Loss Curve



## Temperature sensors mounting

The temperatures indicated on the identification plate of the temperature sensors are to be observed. The temperature sensors are always paired. Only matched pairs are supplied and may not be separated, extended or shortened, since this affects the measuring accuracy. With temperature sensor pairs with a cable length longer than 3 m, we exclusively recommend the use of shielded temperature sensor pairs. In this case, the shields must be installed correctly. Temperature sensors with protection pockets must be inserted up to the stall – and fixed afterwards. With unequal cable lengths or longer than 6 m we recommend exclusively the use of four-wire technology. The temperature sensors can be installed alternatively in protection pockets or directly in the heating and/or cooling agent however always both in the same way. **Asymmetrical mounting, one sensor direct the other with pockets, isn't permitted.** The measuring tip of the temperature sensor pair must be positioned in the center of the cross section of the pipe.




## List of sensor pockets

Temperature sensor	Versions	Pocket	Part number	Material	Temperature range
Ø 6x31mm	Pt500	G3/8"	0460A202	Brass	0...100°C
Ø 6x31mm	Pt500	G1/2"	0460A206	Brass	0...100°C
Ø 6x85mm	Pt500, DIN	G1/2"	0460A207	Stainless	0...150°C
Ø 6x134mm	Pt500, DIN	G1/2"	0460A208	Stainless	0...150°C
Ø 6x174mm	Pt500, DIN	G1/2"	0460A209	Stainless	0...150°C


The resonance frequencies of the protection pockets are outside of the flow velocities at maximum flow (qs).

## Temperature sensors connections



Wire cross section for head sensors ≥ 0,5 mm² (EN 1434-2)

## Temperature sensor installation with cooling applications



## Error messages

The Supercal 5 indicates occurring errors by displaying on the LCD the Err-sign together with a numbered code. If several errors occur at the same time, the numbers of the error codes are added.

1	Temperature reference 1 A/D: A cable of the temperature sensor is interrupted or not connected.
2	Temperature reference 2 A/D: A cable of the temperature sensor is interrupted or not connected.
4	Temperature reference 1 A/D: A cable of the temperature sensor is connected but its value can not be read out.
8	Temperature reference 2 A/D: A cable of the temperature sensor is connected but its value can not be read out.
16	Temperature sensor 1 <= min. Range error
32	Temperature sensor 1 >= max. Range error
64	Temperature sensor 2 <= min. Range error
128	Temperature sensor 2 >= max. Range error
512	The flow rate is higher than 1,5 qs
1024	The SC5 is open
2048	Power outage
4096	M1 Power Supply / M1 Unsupported / Slot left error: Error in module 1: Details must be found into specific module error
8192	M2 Power Supply / M2 Unsupported / Slot right error: Error in module 2: Details must be found into specific module error

Errors will be registered in the error register with its date and time (beginning) and duration (in minutes).

## Communication options

The Supercal 5 can be fitted with up to two different optional communication modules. The optional communication modules can be equipped afterwards, without damaging the verification. The optional modules have no influence on the verified relevant part in the cover of the inte-grator unit. At the latest 6 seconds after the installation, the calculator unit recognizes the plugged-in optional modules and the functions are freely available. When connecting the communication modules, the installation guidance - supplied with the unit - is to be considered.

## Cooling liquids (Glycols)

In the calculator Supercal 5 more than 70 cooling liquids are programmed and many additional mixtures can be specified by software.

**The feature of the calculator Supercal 5 for cooling applications with cooling liquids water mixtures is exclusively to be used with the flow sensor Superstatic 440 (Not to be used with mechanical flow sensors).**

Note: If cooling liquids are used, the calculator or thermal energy meter loses its MID approval.

## Display

The calculator Supercal 5 has the following display sequence:

- Main menu (Billing relevant data)
- Metrological
- Configuration
- Service
- Test Radio

## LCD control concept

The control key can be used to select and confirm the various menus, parameters, or other selection options within the display.



The Right key has two functions:

- One single press and it selects next menu.
- Press it for Two Seconds in the "Overview Menu" and you can enter to the highlighted menu.




Left key is designated to select previous menu.

If you are in any of the menus and you press both key, LEFT and RIGHT for two seconds, you get back to the "Overview Menu".

After 3 minutes the display of the calculator switches automatically back to the main menu.

## LCD (Standard-Anzeige)



## Commissioning Menu



The sealing can be performed via NFC with the Superprog Android application or via optical head or M-Bus with the Superprog Windows application.

To perform the configuration with Superprog Android proceed as follows:

- Open the application on the phone, select the "INSTALL/CONFIGURE" option and follow the instructions on the screen.
- Once the installation assisted by Superprog Android is finished, Superprog Android will ask you to Seal the calculator. Select "Yes".


**Remember that Superprog Windows has more options to configure the Supercal 5.**

To perform the configuration with Superprog Windows proceed as follows:


- Start Superprog Windows on the computer
- Connect to Supercal 5 via the selected interface.
- Configure all the desired values.

- Once you have configured the desired values, press the "WRITE" button to confirm the changes and when you are requested to confirm the changes, you can check the checkbox to Seal the Supercal 5.

If at this point and after configuring the device, you have not yet sealed the Supercal 5, you can do so manually as indicated in the following menu display.




- 1x short press on the left button
- Seal configuration SEAL: seals the configuration and switches to Default Menu




- 1x long press (> 2 seconds) on the left button
- Cumulated energy
- Cumulated volume

## Dimension Supercal 5



## Supercal 5 Lower Part



## Conditions to comply with the directive 2014/32/EU (MID)

- The temperature sensors have to be mounted symmetrically in flow and return and preferably without pockets. If using pocket they must be in accordance with the conformity declaration. Flow and return sensors must be mounted to the bottom of the pockets. Installation places in the flow sensor can be used with the symmetrical installation of the temperature sensor pair. **Asymmetrical mounting of the temperature sensor isn't permitted.**
- In case of permanent mounted temperature sensor pairs the connecting cables must not be shortened. In case of exchangeable temperature sensor pairs according to MID the maximum equal length is 15 m. Wire cross sections according to EN 1434-2. Connection to the calculator according to terminal connection on page 2 by respecting the electrical compatibility Pt 500 of the calculator.
- Straight sections of piping of 3 DN in flow and return of any flow meter or heat meter must be respected. For the Superstatic 440 up to DN 40 (qp10) the straight sections of piping of 3 DN are already included in the length of the flow sensor.
- The selection of the battery has to take place in such a way that it permits at least a supply of auxiliary energy over the duration of the application plus 1 year storage period.
- Information about the measuring stability is described in the conditions for water measurement in accordance with AGFW requirements FW 510. In case of deviating compositions the thermal energy meter must be submitted to periodic control according to the guidelines of Sontex.
- If a customer specific correction curve is applied, a sticker must be placed on the cover of the calculator and completed with the serial number of the sensor head. Replacement of the sensor head, as it is described in the homologation, isn't possible in this case.

## Manufacturer's notice:

The heat / cooling meter Superstatic 5 S is configured and adjusted ex factory to the different sizes of fluid oscillator flow sensors. An optimal measuring accuracy and stability according to EN 1434 class 2 is guaranteed and a free swapping of the sensor head is possible. Sontex declines all responsibility on specific correction curves of the fluid oscillator flow sensors that we're not defined by Sontex.

## Security seals

Seals are country specific; the local regulations must be respected. Against possible manipulation or unauthorized dismantling, the thermal energy meters, the screw connections, as well as the temperature sensors and pockets must be protected with user seals. The seals may be removed only by authorized persons. By neglecting this precaution the guarantee obligation is void. It is important that the seal wires are kept as short as possible and are well strained towards the seals. Only this way, the seal is protected against unauthorized interference.

## Sealing


The sealing concept is subject to country-specific regulations. The sealing points shown here were included in the construction of the Supercal 5.

Once the Supercal 5 is manufactured, it come out from factory as *unsealed*. It mean it has to be installed at least with the following operations:

- Fixing it to its operable and definitive location.
- Installing the two temperatures sensor.
- Installing the power supply if required

The calculator of the Supercal 5 S is then closed and mounted. It is then necessary to seal the calculator either via the menu on the display or via Superprog Android/Windows. If the installer needs to change other metrological parameters, this can be done using the Superprog Android or Superprog Windows software. (Android version is recommended).

From this moment on, and if at any time it is necessary to return to commissioning mode or the "Unsealed" state, the seal shown in the following image must be broken:



## WARNINGS

Before use, read this warnings and the installation guide thoroughly to comprehend its contents. This warnings and the installation guide should be passed on to the end user.

	<b>HANDLE WITH CARE</b>	This is a calibrated measuring instrument that should be handled with care. Dropping the box and/or the device may cause damage, leading to leaks, injury or property damage, result in inaccurate measurements and void any manufacturer's warranty.
	<b>WARNING MOUNTING &amp; SERVICES</b>	Mounting, installing, commissioning and servicing of this product must be done by qualified and trained personnel. Serious injury, leaking and/or property damage may result from the improper installation or use of this product
	<b>WARNING PARTS</b>	Use only the original manufacturer accessories (e.g. gaskets, thermowells, etc) provided with the device. Using other non-original accessories may result in measurement inaccuracy, serious injury, leaking and/or property damage. Such use will also void any manufacturer's warranty.
	<b>WARNING DAMAGES</b>	The device should not be used in systems with temperatures or pressures above the amounts indicated on the device. Such use may result in measurement inaccuracy, irreversible damage to the device, serious injury, leaking and/or property damages. The information on the device plates should be checked prior to installation and the device should only be installed in systems that are within the specifications indicated on the device plates.
	<b>WARNING HIGH TEMPERATURE</b>	High temperatures can lead to burn-related injuries. In systems with medium temperatures above 60°C, the device should be shielded to avoid unintended contact. Beware of the system temperature before installing or working on the device.
	<b>WARNING VIBRATIONS</b>	Mount the flow meter and calculator away from any devices that can generate vibrations. Failure to do so may damage the device and/or result in measurement inaccuracy.
	<b>WARNING MANIPULATE</b>	Loosening or removing any of the flow meter head screws may lead to leaks and/or measurement inaccuracy and will void any manufacturer's warranty.
	<b>WARNING MANIPULATE</b>	It is forbidden to shorten or to extend the cables of the flow meter and of the 2 wires temperature sensors. Such actions may lead to measurement inaccuracy and will void any manufacturer's warranty.
	<b>WARNING INJURIES</b>	The device includes sharp threads that should be handled with care to avoid the risk of injury.
	<b>WARNING INJURIES</b>	The device is heavy and should be handled with care to avoid the risk of injury.

In the case of divergences, the English version takes precedence.  
In caso di divergenze del contenuto, la versione inglese prevale.

## Further information



## Technical support

For technical support contact your local Watts agent or Watts S.r.l directly.

## Declaration of conformity



The detailed declaration of conformity can be found and downloaded on [www.sontex.ch](http://www.sontex.ch)

## Hotline Watts

info@wattsitalia@wattswater.com  
+39 800332595

Technical modifications subject to change without notice



Watts Industries Italia S.r.l  
Via Brenno 21  
IT-20853 Biassono  
Tel. +39 03949861

[www.wattswater.it](http://www.wattswater.it)



