

Vision® Wireless


Wireless 6 or 10 Zones Water Heating Controller Heat & Cool 24 or 230Vac

WFC-03 6Z HC RF 24 / WFC-03 10Z HC RF 24



WFC-03 6Z HC RF 230 / WFC-03 10Z HC RF 230



RF Pairing 



RF Pairing 



DIP switch number	Function	Value (default: OFF)	Configuration	
DIP 1	Pump configuration	OFF	Local (demand on the controller)	
		ON	Global (demand from every controller in the system)	
DIP 2	Actuator types	OFF	Normally closed	
		ON	Normally opened	
DIP 3	Pump start delay (for the first actuator) and actuator stop delay for the last actuator	OFF	2min/5min	
		ON	5min/20min	
DIP 4 and DIP 5	H&C switch control	OFF	OFF	Central
		OFF	ON	Thermostat
		ON	OFF	HCM
		ON	ON	Controller
DIP 6	Anti Grip	OFF	Activated	
		ON	Deactivated	
DIP 7	Humidity management	OFF	Safety	
		ON	Comfort	
DIP 8	Humidity sensor	OFF	Humidity sensor	
		ON	Water sensor	